

INDEX

Chapter 1 Overview

1.1 How to use the User's Manual-----	1-1
1.2 Characteristics of Smart I/O-----	1-2
1.3 Product Configuration of Smart I/O -----	1-3
1.3.1 Type name indication-----	1-3
1.3.2 Characteristics per module-----	1-4
1.3.3 Version Compatibility Table per Smart I/O module -----	1-6

Chapter 2 Product Specification

2.1 General Specification-----	2-1
2.2 Power Specification-----	2-2
2.2.1 Performance Specification-----	2-2
2.3 Digital Input Module Specification-----	2-3
2.3.1 DC 16 point input module : GPL/GDL/GRL/GSL-D22A -----	2-3
2.3.1 DC 32 point input module : GPL/GDL/GRL/GSL-D24A -----	2-4
2.4 Digital Output Module Specification-----	2-5
2.4.1 16 point relay output module : GPL/GDL/GRL/GSL-RY2A -----	2-5
2.4.2 16 point transistor output module : GPL/GDL/GRL/GSL-TR2A -----	2-6
2.4.3 32 point transistor output module : GPL/GDL/GRL/GSL-TR4A -----	2-7
2.5 Digital I/O combined Module Specification-----	2-8
2.5.1 32point I/O combined module (DC16/TR16 point) : GPL/GDL/GFL/GSL-DT4A ----	2-8

2.6 Communication Module Specification-----	2-9
2.6.1 Profibus-DP module specification-----	2-9
2.6.2 DeviceNet module specification-----	2-9
2.6.3 Rnet module specification -----	2-10
2.6.4 Modbus module specification-----	2-10
2.7 Communication Cable Specification -----	2-11
2.7.1 Profibus-DP cable specification-----	2-11
2.7.2 DeviceNet cable specification-----	2-12
2.7.3 Rnet cable specification-----	2-14
2.7.4 Modbus cable specification-----	2-15
2.8 Terminating-----	2-16
2.8.1 Profibus-DP terminating-----	2-16
2.8.2 DeviceNet terminating-----	2-16
2.8.3 Rnet terminating-----	2-17
2.8.4 Modbus terminating-----	2-18

Chapter 3 System Configuration

3.1 Notices in selecting module-----	3-1
3.2 Names of Each Part-----	3-2
3.2.1 Basic system configuration-----	3-2
3.2.2 Names of each part of Smart I/O series-----	3-3
3.3 I/O Wiring Diagram of Communication Module-----	3-9
3.3.1 External connection diagram of Smart I/O module-----	3-9
3.4 Examples of System Configuration-----	3-17
3.4.1 Profibus-DP system-----	3-17
3.4.2 DeviceNet system -----	3-18
3.4.3 Rnet system -----	3-19
3.4.4 Modbus system -----	3-20

Chapter 4 Communication Programming

4.1 Overview-----	4-1
4.2 <i>High Speed Link</i> -----	4-3
4.2.1 Overview-----	4-3
4.2.2 <i>High Speed Link</i> sending/receiving data processing-----	4-4
4.2.3 Operation order by <i>High Speed Link</i> -----	4-5
4.2.4 GMWIN's setting of <i>High Speed Link</i> -----	4-6
4.2.5 KGLWIN Link parameter setting-----	4-14
4.2.6 <i>High Speed Link</i> Communication status flag information-----	4-18
4.2.7 <i>High Speed Link</i> Speed calculation-----	4-21
4.3 Function Block-----	4-25
4.3.1 Overview-----	4-25
4.3.2 Start of GMWIN Function Block-----	4-25
4.3.3 Execution of KGLWIN command-----	4-27

Chapter 5 Profibus-DP Communication

5.1 Overview-----	5-1
5.2 Communication Specification-----	5-1
5.3 Basic Performance-----	5-2
5.3.1 Overview-----	5-2
5.3.2 Operation by <i>High Speed Link</i> -----	5-2
5.3.3 SyCon -----	5-3
5.3.4 Insertion of master module-----	5-4
5.3.5 Master module setting-----	5-5
5.3.6 Insertion of slave-----	5-6
5.3.7 Slave Configuration -----	5-7
5.3.8 Bus parameter setting-----	5-8
5.3.9 Device allocation-----	5-9
5.3.10 Configuration download - -----	5-11

5.3.11 <i>High Speed Link</i> parameter setting in GMWIN-----	5-12
5.3.12 <i>High Speed Link</i> information in GMWIN-----	5-16
5.3.13 <i>High Speed Link</i> parameter setting in KGLWIN-----	5-20

Chapter 6 DeviceNet Communication

6.1 Overview-----	6-1
6.2 Communication Specification-----	6-2
6.3 Communication Parameter Setting-----	6-3
6.3.1 <i>High Speed Link</i> service-----	6-4
6.4 Program Examples-----	6-12
6.4.1 GLOFA-GM series-----	6-12
6.4.2 MASTER-K series -----	6-16

Chapter 7 Rnet Communication

7.1 Overview-----	7-1
7.2 Communication Specification-----	7-1
7.3 Communication Parameter Setting-----	7-2
7.3.1 Overview-----	7-2
7.3.2 <i>High Speed Link</i> communication status flag-----	7-3
7.3.3 GMWIN <i>High Speed Link</i> setting-----	7-3
7.3.4 KGLWIN Link setting-----	7-12
7.4 Program Examples-----	7-22
7.4.1 GLOFA-GM series -----	7-22
7.4.2 MASTER-K series -----	7-24

Chapter 8 Modbus Communication

8.1 Overview-----	8-1
8.2 Communication Specification-----	8-1
8.3 Communication Parameter Setting-----	8-6
8.3.1 GLOFA-GM series -----	8-6
8.3.2 MASTER-K series -----	8-9
8.4 Function Block-----	8-11
8.4.1 GLOFA-GM series -----	8-11
8.4.2 MASTER-K series -----	8-32
8.5 Program Examples-----	8-34
8.5.1 GLOFA-GM series -----	8-34
8.5.2 MASTER-K series -----	8-44

Chapter 9 Installation & Wiring

9.1 Installation-----	9-1
9.1.1 Installation Environment-----	9-1
9.1.2 Notices in installing Profibus-DP module-----	9-2
9.1.3 Notices in installing DeviceNet module-----	9-3
9.1.4 Notices in installing Rnet module-----	9-8
9.1.5 Notices in installing Modbus module-----	9-9
9.1.6 Notices in Handling-----	9-10
9.2 Wiring-----	9-14
9.2.1 Power wiring-----	9-14
9.2.2 I/O Machine Wiring-----	9-16
9.2.3 Grounding wiring-----	9-16
9.2.4 Cable specification for wiring-----	9-17

Chapter 10 Maintenance and Repair

10.1 Repair and Check-----	10-1
10.2 Daily Check-----	10-2
10.3 Regular Check-----	10-4

Chapter 11 Trouble Shooting

11.1 Basic Procedure of Trouble Shooting-----	11-1
11.2 Trouble Shooting-----	11-2
11.2.1 Action method when POWER LED is OFF -----	11-3
11.2.2 Action method when ERR LED is blinking-----	11-4
11.2.3 Action method when RUN LED is OFF -----	11-5
11.2.4 Action method when I/O part does not work normally-----	11-6
11.2.5 Action method when <i>Program Write</i> does not work -----	11-8
11.3 Trouble Shooting Questionnaire-----	11-9

Appendix

A.1 Communication Terminology-----	A-1
A1.1 Profibus-DP -----	A-1
A1.2 DeviceNet -----	A-3
A1.3 Rnet -----	A-4
A1.4 Modbus -----	A-6
A.2 External Dimension-----	A-7