◎ Contents ◎

Chapter 1. General · · · 1-1~1-6

1.1 Guide to Use this Manual · · · 1-1

1.2 Features · · · 1-2

1.3 Terminology · · · 1-4

Chapter 2. System Configuration · · · 2-1~2-6

2.1 Overall Configuration · · · 2-1
  2.1.1 Basic system · · · 2-1
  2.1.2 Cnet I/F System · · · 2-2

2.2 Product functional model · · · 2-4
  2.2.1 Product function Block · · · 2-4
  2.2.2 GM7 Series System Equipment Product · · · 2-5

Chapter 3. General Specification · · · 3-1

3.1 General specifications · · · 3-1

Chapter 4. Names of Parts · · · 4-1~4-6

4.1 Base Unit · · · 4-1
  4.1.1 10-point base unit · · · 4-3
  4.1.2 20-point base unit · · · 4-3
  4.1.3 30-points Base Unit · · · 4-3
  4.1.4 40-Points Base Unit · · · 4-4
  4.1.5 60-Points Base Unit · · · 4-4

4.2 Expansion Module · · · 4-5
  4.2.1 Digital I/O Module · · · 4-5
  4.2.2 A/D · D/A Combination Module · · · 4-5
  4.2.3 Analogue timer Module · · · 4-5
  4.2.4 Option Module · · · 4-6

Chapter 5. CPU ········ 5-1~5-48

5.1 Power Supply Specifications ········ 5-1

5.2 CPU Specifications ········ 5-2

5.3 Operation Processing ········ 5-4
  5.3.1 Operation Processing Method ········ 5-4
  5.3.2 Operation Processing at momentary power failure occurrence ········ 5-5
  5.3.3 Scan time ········ 5-6
  5.3.4 Scan-watchdog timer ········ 5-6
  5.3.5 Timer processing ········ 5-7
  5.3.6 Counter processing ········ 5-9

5.4 Program ········ 5-11
  5.4.1 Program configuration ········ 5-11
  5.4.2 Program execution procedure ········ 5-12
  5.4.3 Task ········ 5-15
  5.4.4 Error handling ········ 5–22
  5.4.5 Precautions when using special modules ········ 5–23

5.5 Operation modes ········ 5-24
  5.5.1 RUN mode ········ 5-24
  5.5.2 STOP mode ········ 5-25
  5.5.3 PAUSE mode ········ 5-25
  5.5.4 DEBUG mode ········ 5-25
  5.5.5 Operation mode Change ········ 5-26

5.6 Functions ········ 5-28
  5.6.1 Restart mode ········ 5-28
  5.6.2 Self-diagnosis ········ 5-30
  5.6.3 Remote function ········ 5-30
  5.6.4 I/O Force On/Off function ········ 5-31
  5.6.5 Direct I/O operation function ········ 5-32
  5.6.6 External device error diagnosis function ········ 5-32

5.7 Memory Configuration ········ 5–35

5.8 I/O No. Allocation Method ········ 5–37

5.9 Built-in Flash Memory ········ 5–37
  5.9.1 Structure ········ 5-37
  5.9.2 Usage ········ 5-38

5.10 External Memory Module ········ 5–40
  5.10.1 Structure ········ 5-40
  5.10.2 Usage ········ 5-40

5.11 Battery 5–43

5.12 RTC module 5–44

Chapter 6. Input and Output Modules 6-1~6-13

6.1 Input and Output Specifications 6-1

6.2 Digital Input Specifications 6–2
  6.2.1 Base Unit 6-2
  6.2.2 Extended Module 6-6

6.3 Digital output Specifications 6–7
  6.3.1 Base unit (Relay output) 6-7
  6.3.2 Base unit (Transistor output) 6-10
  6.3.2 Extended Module 6-13

Chapter 7. Usage of Various Functions 7-1~7-52

7.1 Built-in function 7–1
  7.1.1 High-speed counter function 7-1
  7.1.2 Pulse Output Function 7-8
  7.1.3 Pulse Catch function 7-18
  7.1.4 Input Filter function 7-20
  7.1.5 PID Control function 7-21
  7.1.6 External Interrupt function 7-40

7.2 Special Module 7–42
  7.2.1 A/D-D/A Combination 7–42
  7.2. 2 Analogue Timer 7–50

Chapter 8. Communication Function 8-1~8-115

8.1 Direct Protocol Communication 8–1
  8.1.1 Introduction 8-1
  8.1.2 System Configuration method 8-2
  8.1.3 Frame Structure 8-5
  8.1.4 List of Commands 8-8
  8.1.5 Data Type 8-9
  8.1.6 Execution of Commands 8-10
  8.1.7 1:1 Built-in Communication between GM7’ s 8-30
  8.1.8 Error Codes 8-48

8.2 User Defined Protocol Communication 8–50
  8.2.1 Introduction 8-50

8.2.2 Parameter Setting · 8-51
8.2.3 Function Block · 8-58
8.2.4 Example of Use 1) · 8-59
8.2.5 Example of Use 2) · 8-76

8.3 Modbus Protocol Communication · 8–85
8.3.1 Introduction · 8-85
8.3.2 Basic Size · 8-85
8.3.3 Parameter Setting · 8-89
8.3.4 Function Block · 8-91
8.3.5 Example of Use · 8-108

Chapter 9. Installation and Wiring · 9-1~9-11

9.1 Installation · 9-1
9.1.1 Installation Environment · 9-1
9.1.2 Handling Instructions · 9-4
9.1.3 Connection of expansion module · 9-7

9.2 Wiring · 9-8
9.2.1 Power supply Wiring · 9-8
9.2.2 I/O devices Wiring · 9-10
9.2.3 Grounding · 9-10
9.2.4 Cable Specifications for Wiring · 9-11

Chapter 10. Maintenance · 10-1~10-2

10.1 Maintenance and Inspection · 10-1

10.2 Daily Inspection · 10-1

10.3 Periodic Inspection · 10-2

Chapter 11. Trouble Shooting · 11-1~11-13

11.1 Basic Procedures of Troubleshooting · · · · · · · · · · · · · · · · · · · 11-1

11.2 Troubleshooting · 11-1

11.2.1 Troubleshooting flowchart used when the power LED turns off 11-2

11.2.2 Troubleshooting flowchart used when the error LED is flickering 11-3

11.2.3 Troubleshooting flowchart used when the RUN LED turns off · 11-4

11.2.4 Troubleshooting flowchart used when the I/O devices doesn’t operate normally · 11-5

11.2.5 Troubleshooting flowchart used when a program can’t be written to the CPU · 11-7

11.3 Troubleshooting Questionnaire · 11-8

11.4 Troubleshooting Examples · 11-9

11.4.1 Input circuit troubles and corrective actions · · · · · · · · · · · · 11-9

11.4.2 Output circuit troubles and corrective actions · · · · · · · · · · 11-10

11.5 Error code list · 11-12

Appendix · App1-1~App4-1

Appendix 1 System definitions · App1-1

Appendix 2 Flag list · App2-1

Appendix 3 Function / Function block list · · · · · · · · · · · · · · · · · · App3-1

Appendix 4 Dimensions · App4-1