

This user's manual describes functions of Cnet I/F module.
Please read this manual carefully to understand the functions thoroughly prior to system design.

Revision record

Revision record	Date of issue revised	Contents revised
1 st edition		1 st print
1 st revision	2000.01.10	<ul style="list-style-type: none">- GM7 Cnet I/F module added- Functions of frame editor Version 2.0 added

Chapter 1 Introduction	1-1~1-7
1.1 Module selection per CPU type	1-2
1.2 Functions of Version 2.0	1-3
1.2.1 Version check	1-3
1.2.2 Added functions introduction of Version 2.0	1-6
1.2.3 Established functions	1-7
1.2.4 Frame editor Version 2.0	1-7
1.2.5 Added function of Version 2.0	1-7
 Chapter 2 Definition of terms	 2-1~2-6
 Chapter 3 Product specification	 3-1~3-12
3.1 General specification	3-1
3.2 Performance specifications	3-2
3.3 Cable specifications	3-4
3.4 Terminating resistance	3-5
3.5 Structure	3-7
3.5.1 Part names of G3L-CUEA	3-7
3.5.2 Part names of G4L-CUEA	3-8
3.5.3 Part names of G6L-CUEB	3-9
3.5.4 Part names of G6L-CUEC	3-10
3.5.5 Part names of G7L-CUEB	3-11
3.5.6 Part names of G7L-CUEC	3-12
 Chapter 4 Performance specification	 4-1~4-33
4.1 Operating mode setting	4-1
4.1.1 Channel operation in interlocking mode	4-3
4.1.2 Channel operation in stand-alone mode	4-4
4.1.3 Channel operation in self diagnosis mode (Loop Back)	4-5
4.2 Method of serial interface	4-6
4.2.1 RS-232C interface	4-6
4.2.2 RS-422 interface	4-9

4.3 How to set transmission specifications	4-11
4.3.1 Setting items	4-11
4.3.2 How to set	4-12
4.3.3 Reading setting values	4-16
4.3.4 Transmission specification setting of Gm7 series	4-17
4.4 How to connect to modem	4-19
4.4.1 Connection to dedicated modem (RS-232C)	4-20
4.4.2 Connection to dial-up modem (RS-232C)	4-27

Chapter 5 Frame Editor 5-1~5-43

5.1 Basic functions	5-1
5.2 Screen configuration and menu	5-2
5.2.1 Basic parameter setting	5-6
5.2.2 Frame setting	5-7
5.2.3 Frame writing/reading	5-23
5.2.4 Monitor function	5-27
5.3 Managing function of flash memory	5-31
5.3.1 Writing of flash memory	5-31
5.3.2 Reading of flash memory	5-34
5.4 Changing of online mode	5-35
5.4.1 Changing of local operating mode	5-35
5.4.2 Changing of remote operating mode	5-39

Chapter 6 System configuration 6-1~6-11

6.1 System configuration available	6-1
6.1.1 1:1 connection (no modem) to PC	6-1
6.1.2 1:1 dedicated modem connection to PC	6-2
6.1.3 Modem connection to PC & communication between Cnet I/F modules	6-3
6.1.4 Communication between PC and Cnet using interlocking channel	6-4
6.1.5 Interlocking & stand-alone channel communication	6-5
6.1.6 Dedicated communication to PC & other company's RS-422 communication	6-6
6.1.7 Optical modem communication for mobile communication	6-7
6.1.8 Wireless modem communication between revolution bodies	6-8
6.1.9 TM/TC communication system	6-9

6.2 System configuration unavailable	6-10
6.2.1 Dial-up modem communication between Cnet I/F modules.....	6-10
6.2.2 GMWIN connection using RS-422 channel of Cnet I/F module	6-11

Chapter 7 Communication program 7-1~7-132

7.1 User defined communication	7-1
7.1.1 Introduction	7-1
7.1.2 User defined operation	7-2
7.1.3 User defined Function Block (SND_MSG ,RCV_MSG)	7-5
7.1.4 Example of user defined programming	7-12
7.1.5 User defined communication for Gm7 series	7-25
7.2 Dedicated communication slave	7-34
7.2.1 Introduction	7-34
7.2.2 Frame structure	7-35
7.2.3 List of commands.....	7-38
7.2.4 Data type	7-40
7.2.5 Execution of commands (Ex.).....	7-42
7.3 Dedicated communication master (communication between Cnets).....	7-94
7.3.1 Introduction	7-94
7.3.2 Function Block for dedicated communication.....	7-95
7.3.3 How to use dedicated Function Block.....	7-97
7.3.4 Dedicated communication master for G7L-CUEC.....	7-102
7.4 Other company's dedicated mode	7-109
7.4.1 Introduction	7-109
7.4.2 Operating mode & downloading of communication driver	7-110
7.4.3 Specifications of A. B communication driver	7-114
7.4.4 Specifications of MODBUS communication driver	7-119
7.5 GMWIN remote connection	7-122
7.5.1 Introduction	7-122
7.5.2 GMWIN remote connection.....	7-122
7.5.3 Remote connection between Cnet I/F modules.....	7-129

Chapter 8 Exercising program 8-1~8-66

8.1 TM (Tele Metering) system using dedicated modem.....	8-1
8.1.1 Exercising program	8-2

8.2 Communication system between Cnet I/F modules using optical modem	8-8
8.2.1 Exercising program	8-9
8.3 GMWIN connection using dial-up modem	8-21
8.3.1 Exercising program	8-21
8.4 Communication with GOLDSEC MJUC24	8-25
8.4.1 Exercising program	8-25
8.5 Communication with MASTER-K 1000H	8-30
8.5.1 Exercising program	8-30
8.6 Communication with HEX communication equipment	8-36
8.6.1 Exercising program	8-36
8.7 Example of using G7L-CUEC	8-45
8.7.1 Dedicated communication master	8-45
8.7.2 User's definition	8-53

Chapter 9 Diagnosis function 9-1~9-6

9.1 Loop-Back self diagnosis	9-1
9.1.1 Principle of operation	9-1
9.1.2 Procedure of Loop-Back self diagnosis	9-2
9.1.3 Operation of Loop-Back test LED	9-3
9.2 Diagnosis during power on	9-6

Chapter 10 Installation and Testing operation 10-1~10-9

10.1 Installation and testing operation	10-1
10.1.1 Mounting and installation	10-2
10.1.2 Cautions during system installation	10-4
10.1.3 Testing operation	10-6
10.2 Maintenance and Check	10-8
10.2.1 Daily check	10-8
10.2.2 Regular check	10-9

Chapter 11 Troubleshooting 11-1~11-11

11.1 Abnormal operations	11-1
11.2 Troubleshooting by each error code	11-3
11.2.1 Error code ERR-1, ERR-2 : hardware & system error	11-3

11.2.2 Error code ERR-3 : communication command error	11-5
11.2.3 Error code ERR-4, ERR-5 : Receive monitor data error	11-7
11.2.4 Error code ERR-6, ERR-7 : Transmission monitor data error	11-8
11.2.5 Error code ERR-8, ERR-9 : Error on dedicated communication	11-9
11.2.6 Error code ERR-10 : error on GMWIN connection	11-11

Appendix **A-1~A-15**

A.1 LED indication specification	A-1
A.1.1 Applicable type	A-1
A.1.2 LED indication specification during normal operation	A-1
A.1.3 LED indication specification during abnormal operation	A-5
A.1.4 LED indication specification during power on	A-6
A.2 Error code table	A-7
A.2.1 Error code for user defined communication	A-7
A.2.2 Error code for dedicated slave communication	A-9
A.2.3 Error code for dedicated master communication	A-11
A.3 Dimensions of appearance	A-12