

# CONTENTS

## Chapter 1. INTRODUCTION

## Chapter 2. SPECIFICATIONS

<b>2.1</b>	<b>General Specifications</b> .....	<b>2-1</b>
<b>2.2</b>	<b>Performance Specifications</b> .....	<b>2-2</b>
2.2.1	Basic performance specification .....	2-2
2.2.2	Input specification .....	2-3
2.2.3	Limit switch(L/S) input specification .....	2-3
2.2.4	Transister output specification .....	2-3
<b>2.3</b>	<b>Names of Parts and Functions</b> .....	<b>2-4</b>
2.3.1	Names of Parts and Functions .....	2-4
2.3.2	Function of LED Indicators .....	2-6
2.3.3	DIP Switch Setting Part .....	2-7
2.3.4	Input / Output Terminal Block .....	2-8
<b>2.4</b>	<b>Interface with External Devices</b> .....	<b>2-10</b>
<b>2.5</b>	<b>Output Mode of Encoder</b> .....	<b>2-12</b>
<b>2.6</b>	<b>Function Descriptions</b> .....	<b>2-13</b>
2.6.1	Operation Modes .....	2-13
2.6.2	Comparison Signal Output .....	2-15
2.6.3	Home Signal .....	2-17
2.6.4	Carry Signal .....	2-18
2.6.5	Borrow Signal .....	2-18

## Chapter 3. INSTALLATION AND WIRING

<b>3.1</b>	<b>Installation</b> .....	<b>3-1</b>
3.1.1	Installation Ambience .....	3-1
<b>3.2</b>	<b>Wiring Precautions</b> .....	<b>3-1</b>
<b>3.3</b>	<b>Wiring Example</b> .....	<b>3-2</b>
3.3.1	5VDC Voltage Output Type Encoder .....	3-2
3.3.2	24VDC NPN Open Type Encoder .....	3-3
3.3.3	24VDC PNP Open Collector Encoder .....	3-4

## Chapter 4. FUNCTION BLOCK

<b>4.1</b>	<b>Insertion of the Function Block for High Speed Counter on the GMWIN .....</b>	<b>4-1</b>
<b>4.2</b>	<b>Local Function Block .....</b>	<b>4-2</b>
4.2.1	The specification of the preset value(HSC_PRE) .....	4-2
4.2.2	The specification of the comparison value (HSC_CMP) .....	4-3
4.2.3	Writing the operating Information(HSC_WR) .....	4-4
4.2.4	Reading the value of the operating status(HSC_RD) .....	4-5
<b>4.3</b>	<b>Remote Function Block .....</b>	<b>4-6</b>
4.3.1	The specification of the preset value (HSCR1PRE) .....	4-6
4.3.2	The specification of the comparison value (HSCR1CMP) .....	4-7
4.3.3	Writing the operating information (HSCR1WR) .....	4-8
4.3.4	Reading the value of the operating status(HSCR1RD) .....	4-9
<b>4.4</b>	<b>Error code on the function block.....</b>	<b>4-10</b>

## Chapter 5. GM PROGRAMMING

<b>5.1</b>	<b>Programming Examples .....</b>	<b>5-1</b>
5.1.1	Enabling the counter operation .....	5-2
5.1.2	Preset .....	5-3
5.1.3	Setting the comparison value .....	5-4
5.1.4	Setting the magnitude comparison values .....	5-5
5.1.5	Reading the current count value .....	5-6
5.1.6	Enabling the external output .....	5-7
5.1.7	Coincidence reset .....	5-8
5.1.8	Carry / Borrow reset .....	5-9
5.1.9	Enabling the home latch .....	5-10
5.1.10	Read/Write when the high speed counter module is mounted onto the remote station.....	5-11
<b>5.2</b>	<b>Application Examples .....</b>	<b>5-13</b>
5.2.1	Program for moving the cart .....	5-13

## Chapter 6. BUFFER MEMORY AND I/O SIGNAL CONFIGURATION

<b>6.1</b>	<b>Operating block diagram</b>	<b>6-1</b>
<b>6.2</b>	<b>Input / Output signal configuration</b>	<b>6-3</b>
6.2.1	G3F-HSCA	6-3
6.2.2	G4F-HSCA / G6F-HSCA	6-5
6.2.3	Functions of I/O Signals	6-6
<b>6.3</b>	<b>Buffer memory configuration</b>	<b>6-8</b>
6.3.1	Buffer memory configuration	6-8
6.3.2	The contents and data configuration of buffer memory	6-9

## Chapter 7. MK PROGRAMMING

<b>7.1</b>	<b>Buffer Memory Read / Write</b>	<b>7-1</b>
7.1.1	Read from the Buffer Memory (GET,GETP)	7-1
7.1.2	Write to the Buffer Memory (PUT,PUTP)	7-3
<b>7.2</b>	<b>Programming Examples</b>	<b>7-5</b>
7.2.1	Setting Preset Value	7-5
7.2.2	Setting Comparison Value	7-7
7.2.3	Setting Out Data	7-7
7.2.4	Reading Current Count Value	7-8
7.2.5	Enable Output	7-8
7.2.6	Enabling Home Latch	7-9
7.2.7	Coincidence Reset	7-10
7.2.8	Carry / Borrow Reset	7-10
<b>7.3</b>	<b>Application Examples</b>	<b>7-11</b>
7.3.1	Program for moving the cart	7-11
7.3.2	Program for Control of the Constant Angle rotation of the Turntable	7-16

## Chapter 8. TROUBLESHOOTING

<b>8.1</b>	<b>Troubleshooting</b>	<b>8-1</b>
8.1.1	The LED status of High Speed Counter Module	8-1
8.1.2	The counting status High Speed Counter Module	8-1
8.1.3	The output status of High Speed Counter Module	8-1
<b>8.2</b>	<b>Troubleshooting Procedure</b>	<b>8-2</b>
8.2.1	LED indication Is Incorrect	8-2
8.2.2	Count Operations Do Not Execute	8-3
8.2.3	Counter Value Is Incorrect	8-4
8.2.4	Output Operations Do Not Execute	8-5
<b>8.3</b>	<b>Error LED List</b>	<b>8-6</b>

## Chapter 9. DIMENSIONS

9.1 Dimensions.....	9-1
---------------------	-----