

CONTENTS

Chapter 1. INTRODUCTION

1.1 Features	1-1
1.2 Glossary	1-2
1.2.1 A-Analog Value	1-2
1.2.2 D-Digital Value	1-2
1.2.3 Compensating Wire	1-2
1.2.4 Thermocouple	1-3
1.2.5 Temperature Conversion Characteristics	1-3
1.2.6 Burn-out Detection	1-3
1.2.7 Reference Junction Compensation (RJC)	1-3

Chapter 2. SPECIFICATIONS

2.1 General Specifications	2-1
2.2 Performance Specifications	2-2
2.3 Names of Parts and Functions	2-3
2.3.1 G3F-TC4A	2-3
2.3.2 G4F-TC2A	2-4
2.3.3 G6F-TC2A	2-4
2.4 I/O Conversion Characteristics	2-5
2.4.1 Temperature Conversion Characteristics	2-5
2.4.2 Conversion Speed	2-5
2.4.3 Accuracy	2-6
2.4.4 Burn-out Detection	2-6
2.4.5 Displaying Temperature Conversion Value	2-7
2.4.6 Displaying Digital Value	2-7

Chapter 3. INSTALLATION AND WIRING

3.1 Installation	3-1
3.1.1 Installation Ambience	3-1
3.1.2 Handling Precautions	3-1
3.2 Wiring	3-2
3.2.1 Wiring Precautions	3-2

Chapter 4. FUNCTIONS BLOCKS

4.1	Insertion of the Function Blocks for Thermocouple Input Module on the GMWIN	4-1
4.2	Local Function Block	4-2
4.2.1	Module Initialization (G3F-TC4A:TC4INI, G4F-TC2A/G6F-TC2A:TC2INI)	4-2
4.2.2	Module Reading (Array Type) (G3F-TC4A:TC4ARD, G4F-TC2A/G6F-TC2A:TC2ARD)	4-3
4.2.3	Module Reading (Stand-alone Type) (G3F-TC4A : TC4RD, G4F-TC2A/G6F-TC2A:TC2RD).....	4-4
4.3	Remote Function Block.....	4-5
4.3.1	Module Initialization (G3F-TC4A:TCR4INI, G4F-TC2A:TCR2INI, G6F-TC2A:TCR62INI)	4-5
4.3.2	Module Reading (Array Type) (G3F-TC4A:TCR4RD, G4F-TC2A:TCR2RD, G6F-TC2A:TCR62RD)	4-6
4.4	Errors Indicated During Execution Of Function Block	4-7
4.4.1	Errors Indicated by the Output Variable,STAT	4-7
4.4.2	Errors Indicated by the Output Variable,ALM_CODE in the array type temperature Conversion value reading function block(G3F-TC4A:TC4ARD,TCR4RD,G4F-TC2A:TC2ARD,TCR2RD G6F- TC2A:TC2ARD,TCR62RD).....	4-7

Chapter 5. PROGRAMMING

5.1	A Program for Converting a Detected Temperature Value(° C) into Fahrenheit (° F) and Outputting as a BCD Value	5-1
5.2	A Program for Magnitude Comparison of a Detected Temperature Value	5-6
5.3	A Program Used When Mounting a Thermocouple Input Module on the Remote I/O Station	5-9

Chapter 6. BUFFER MEMORY CONFIGURATION AND FUNCTIONS

6.1	Buffer Memory Configuration	6-1
6.1.1	G3F-TC4A Buffer Memory	6-1
6.1.2	G4F-TC2A/G6F-TC2A Buffer Memory	6-3
6.2	Buffer Memory Functions	6-4
6.2.1	Specifying Channel Enable/Disable (G3F-TC4A : Address 0, G4F-TC2A/G6F-TC2A : Address 0)	6-4
6.2.2	Specifying the Type Of Thermocouple (G3F-TC4A : Address 1 To 16, G4F-TC2A G6F-TC2A : Address 1 to 4)	6-4
6.2.3	Temperature Conversion Value	6-5
6.2.4	Digital Conversion Value	6-5
6.2.5	Error Code	6-6
6.2.6	Setting SET Data (G3F-TC4A : Address 65, G4F-TC2A G6F-TC2A : Address 17)	6-6

6.2.7	Information on Run Channel (G3F-TC4A : Address 66, G4F-TC2A/G6F-TC2A : Address 18)	6-7
6.2.8	Information on Thermocouple Type Specification Error (G3F-TC4A : Address 67, G4F-TC2A /G6F-TC2A : Address 19)	6-7

Chapter 7. DEDICATED INSTRUCTIONS FOR SPECIAL MODULES (Read from/Write to Buffer Memory)

7.1	Local	7-1
7.1.1	Read from Buffer Memory....GET, GETP	7-1
7.1.2	Write to Buffer Memory.....PUT, PUTP	7-2
7.2	Remote	7-3
7.2.1	Read from Buffer Memory....RGET	7-3
7.2.2	Write to Buffer Memory.....RPUT	7-4

Chapter 8. PROGRAMMING

8.1	Basic Programming	8-1
8.1.1	G3F-TC4A	8-1
8.1.2	G4F-TC2A	8-2
8.2	Application Programming	8-3
8.2.1	A Program for Converting a Detected Temperature Value(°C) into Fahrenheit(°F) and Outputting as a BCD Value	8-3
8.2.2	A Program for Magnitude Comparison of a Detected Temperature Value	8-5
8.2.3	A Program Used When Mounting a Thermocouple Input Module on the Remote I/O Station	8-7

Chapter 9. TROUBLESHOOTING

9.1	Errors Indicated by Run LED Flickering	9-1
9.2	Troubleshooting Procedure	9-1
9.2.1	RUN LED Flickering	9-1
9.2.2	RUN LED Off	9-2
9.2.3	Temperature Conversion Value Fluctuates Excessively	9-2
9.2.4	Input Value of the Thermocouple does not Correspond to the Detected Temperature Value	9-3
9.2.5	The LED Display of G3F-TC4A Indicates Error	9-4
9.2.6	Thermocouple Input Module Hardware Defect	9-4

Chapter 10. DIMENSIONS

10.1	G3F-TC4A Dimensions	10-1
10.2	G4F-TC2A Dimensions	10-2

10.3	G6F-TC2A Dimensions	10-3
------	---------------------------	------

Appendix

APPENDIX 1

1.1	Thermoelectromotive Force Tables	A-1
1.2	Thermocouple	A-5
1.2.1	Normal and Overheat Temperature Limits	A-5
1.2.2	Temperature Tolerances	A-6
1.3	Compensating Wire	A-7
1.3.1	Types and Specifications of Compensating Wire	A-7